


# HEICO-TEC® EXPANSION BOLT

## Tolerances Expansion Bolt:

Form		Circularity
		Cylindricity
Orientation		Parallelism
		Perpendicularity
Location		Position
		Concentricity



The sum of all tolerances must be smaller than H11; i.e. the bores must lie between 2 concentric cylinders with diameters  $\varnothing_{db}$  and  $\varnothing_{db} H11$ .  
 If the bores are outside the tolerance, it is advisable to drill them out together to a uniform dimension, which is then within the tolerance H8 over the entire length of the bore.